

Warning:

This equipment should be installed by a qualified individual. Using this equipment for purposes other than those originally intended is prohibited. **Do not use this equipment as a bench.**

Recommendations:

As set out in French Standard NF S52-400 the following is recommended:

- keep these instructions for subsequent reference (inspection, maintenance, etc.).
- periodically carry out predictive maintenance.
- depending on how much it is used have the equipment serviced yearly or every few years.

Pack list:

Pack Ref.	6669/40 Reel 5 m	6670/40 Reel 4 m	6672/40 Reel 2 m	6670/90 Pair of uprights M'2009	No. of Packages
6669C Carpet Reel Trolley 5 m	1	-	-	1	2
6670D Carpet Reel Trolley 4 m	-	1	-	1	2
6672D Carpet Reel Trolley 2 m	-	-	1	1	2
Volume (m³) Weight (kg) Dimensions (mm)	0.1485 43 5800 x 160 x 160	0.1234 37 4820 x 160 x 160	0.0704 24 2750 x 160 x 160	0.378 27 1000 x 700 x 540	

Quantities required:

- Exercise floor carpet (ref.: 6380 & 6390): 2x 5 m reel trolleys (ref.: 6669C) and 1x 4 m reel trolley (ref.: 6670D)
- Rhythmic gymnastics carpet (ref.: 6655 & 6656): 3x 4 m reel trolleys (ref.: 6670D) and 1x 2 m reel trolley (ref.: 6672D) Constantly aiming to improve our products, we reserve the right to make changes to the equipment and dimensions without further discussion.

I. Assembling the reel trolley (two persons recommended):

Note: prepare a clean area for assembling the reel trolley.

- 1 Fit each end of the reel (7) to the machined shaft (22) of the uprights (2) & (3). The 3rd castor wheel (16) of the uprights (2) & (3) must point inwards (see Fig. 1 & 2).
- 2 Tighten the screws (9) and (11) to fix the assembly (see Fig. 1 & 2).





- II. Using the reel trolley (two persons recommended):
- 1 To roll up the different widths of carpet, start with the widths at the edge of the exercise floor.
- 2 Position the reel trolley parallel to the end of the width and centred. Fold back the other end of the width opposite the reel trolley, then pull it close to the reel trolley as shown in **Figure 3**.
- 3 Raise all the clips (6) on the reel (7) as shown in Figure 4.
- 4 Place and hold the end of the carpet against the clips (6) (see Fig. 4 & 5). This means that the carpet will be rolled up with the pile facing in. Centre the carpet (symmetrically in relation to the end clips (6)) on the reel (7)
- 5 When the carpet is in position, push back each clip (6) to secure the start of the carpet.





- 6 Start rolling by turning the hand-wheel (4). The second person must guide the second upright (3) to keep the carpet correctly rolled and straight (see Fig. 6).
- 7 If the carpet goes out of line and starts to form a cone, use the handle to push or pull the upright (2) in the direction indicated by the arrows (see Fig. 7 or 8).
- 8 When the carpet has been rolled up, secure with three hook-and-loop strips (18) (at each end and in the middle).

III. Maintenance:

- 1 Regular cleaning of the apparatus will make it easier to spot any problems(distortion, breakage or corrosion).
- 2 Before each use, make a thorough check on good condition and correct operation of wear parts and safety elements:
 - check the condition and operation of the clips (6) and castor wheels (16).
 - check the tightness of fit of the following items: the clips (6) on the reel (7), the machined shaft (22) of the uprights (2) & (3) on the reel (7), the hand-wheel (4) and the stop ring (5) on the machined shaft (22), the castor wheels (16) on the uprights (2) & (3).

3 - Important:

- If a problem is found or suspected, do not use the equipment until it has been checked by a technician.
- Any damaged or distorted component should be replaced as quickly as possible.

IX. Storage:

Always store the equipment away from humidity and heat.

