

**PROTECTION PAD, SANDOWS,
SPRINGS KITS for MINI-TRAMP**

**5020A - 5040A
5065
5030 - 5055**

I . WARNING :

Before each use, you must check that the bed tensioner system is correct (no slack springs or damaged sandows), that the protection pad is well attached, that the stability of the apparatus is good and that the height adjustment mechanism is secured and locked.

This apparatus must be used by only one person at once and under supervision.
GYMNOVA is not responsible if apparatus is misused.

II . COMPOSITION OF THE PACKAGES :

1 . Set of alternative sandows (Réf. : 5020A) :

- 2 Yellow plastic tensioners for mini-tramp (Réf: 500/09)
- 2 Beige and red sandows, 10 mm diameter, 5,70 m long (Réf: 500/08)
- 4 White elastow (ref. : SLG040018)
- 4 Opened and nicked "S" (Réf. : QESS0021NI)

2 . Complete alternative protection pad (Réf. : 5040A) :

- 1 Protection pad for mini-tramp (Réf. : 504/01)
- 4 White elastow (ref. : SLG040018)

3 . Set of alternative springs (Réf. : 5065) :

- 32 Springs for mini-tramp (Réf. : 521/01)

III . ASSEMBLY OF THE CANVAS :

1 . For mini-tramp with sandows (Réf. : 5000A) :

- Stretch the canvas with the sandows as shown on (Drg 1) (the sandows are located around the frame).
- The extremities of the sandows are stopped as shown on Drawing 2.

2 . For mini-tramp with springs (Réf. : 5010A - 5050A) :

- Stretch the canvas with the springs, in beginning by the 4 angles (for 5050A only) and so on, (Drg 3).


IV . INSTALLATION OF THE PROTECTION PAD :

1 . For mini-tramp with PVC coated canvas "SPORTEX" designed (Réf. : 5000A - 5010A) :


- Attach protection on the fabric using the elastows while passing the loop through eyelets of the fabric then its of protection. Then by the other eyelets protection, in the reverse direction (Drg. 5).
- Lock protection by threading the button in the loop (Drg. 4) (under the fabric).

2 . Case of the minis-tramp with fabric of braided bands Nylon (Réf.: 5050A) :


- Attach protection on the fabric using the elastows while passing the loop by the hooks of the 2 springs corresponding to the position of protection, and by the eyelets of the protection of the fabric. Then by the other eyelets protection, in the reverse direction (Drg.5).
- Lock protection by threading the button in the loop (Drg. 4) (under the fabric).



Drg. 2



Drg. 1



Drg. 4



Drg. 4

Drg 3.

